


















ASSEMBLY GUIDE

ARENA LEGGERO














1




2








5




6








9




10




11



12







service@arozzi.com



support@arozzi.se

